



FITS SERIES 2 & 3 ATTACHMENTS



STALL TYPE INSTALLATION 1/16" / 1.59 mm JIFFY KEY



FOR 12 POINT CONFIGURATION ADD X AFTER SOCKET OR SOCKET ACCESSORY ASSEMBLY NUMBER.

LENGTH OF SOCKET

JIFFY KEY HEX	SOCKET HEX	DESCRIPTION	1/4"	1/2"	1"	1 1/2"	2"	2 1/2"	3"
1/16 1.59 mm	7/32 5.56 mm	SOCKET ACCESSORY ASSEMBLY	18159	18160	18161	18162	18163	18164	18165
		SOCKET	12679	12680	12681	12682	12683	12684	12685
		JIFFY KEY STALL	18127	18128	18129	18130	18131	18132	18133
	1/4 6.35 mm	SOCKET ACCESSORY ASSEMBLY	18166	18167	18168	18169	18170	18171	18172
		SOCKET	12686	12687	14446	12688	12689	12690	12691
		JIFFY KEY STALL	18127	18128	18129	18130	18131	18132	18133
	9/32 7.14 mm	SOCKET ACCESSORY ASSEMBLY	18173	18174	18175	18176	18177	18178	18179
		SOCKET	12692	12693	12694	12695	12696	12697	12698
		JIFFY KEY STALL	18127	18128	18129	18130	18131	18132	18133
	5/16 7.93 mm	SOCKET ACCESSORY ASSEMBLY	18180	18181	18182	18183	18184	18185	18186
		SOCKET	12699	12700	14445	12701	12702	12703	12704
		JIFFY KEY STALL	18127	18128	18129	18130	18131	18132	18133
	11/32 8.73 mm	SOCKET ACCESSORY ASSEMBLY	18187	18188	18189	18190	18191	18192	18193
		SOCKET	12705	12706	12707	12708	12709	12710	12711
		JIFFY KEY STALL	18127	18128	18129	18130	18131	18132	18133