



FITS SERIES 2 & 3 ATTACHMENTS



STALL TYPE INSTALLATION

3/32" / 2.38 mm JIFFY KEY



FOR 12 POINT CONFIGURATION ADD X AFTER SOCKET OR SOCKET ACCESSORY ASSEMBLY NUMBER.

LENGTH OF SOCKET

JIFFY KEY HEX	SOCKET HEX	DESCRIPTION	1/4"	1/2"	1"	1 1/2"	2"	2 1/2"	3"
3/32" 2.38 mm	5/16" 7.93 mm	SOCKET ACCESSORY ASSEMBLY	18236	18237	18238	18239	18240	18241	18242
		SOCKET	12699	12700	14445	12701	12702	12703	12704
		JIFFY KEY STALL	18141	18142	18143	18144	18145	18146	18147
	1 1/32" 8.73 mm	SOCKET ACCESSORY ASSEMBLY	18243	18244	18245	18246	18247	18248	18249
		SOCKET	12705	12706	12707	12708	12709	12710	12711
		JIFFY KEY STALL	18141	18142	18143	18144	18145	18146	18147
	3/8" 9.52 mm	SOCKET ACCESSORY ASSEMBLY	18250	18251	18252	18253	18254	18255	18256
		SOCKET	12767	12768	12769	12770	12771	12772	12773
		JIFFY KEY STALL	18141	18142	18143	18144	18145	18146	18147
	7/16" 11.11 mm	SOCKET ACCESSORY ASSEMBLY	18257	18258	18259	18260	18261	18262	18263
		SOCKET	12872	12873	12874	12875	12876	12877	12878
		JIFFY KEY STALL	18141	18142	18143	18144	18145	18146	18147
	1/2" 12.7 mm	SOCKET ACCESSORY ASSEMBLY	18759	18760	18761	18762	18763	18764	18765
		SOCKET	18485	18486	18487	18488	18489	18490	18491
		JIFFY KEY STALL	18141	18142	18143	18144	18145	18146	18147