



# FITS SERIES 2 & 3 ATTACHMENTS



## STALL TYPE INSTALLATION 3/16" / 4.76 mm JIFFY KEY



FOR 12 POINT CONFIGURATION ADD X AFTER SOCKET OR SOCKET ACCESSORY ASSEMBLY NUMBER.

### LENGTH OF SOCKET

JIFFY KEY HEX	SOCKET HEX	DESCRIPTION	1/4"	1/2"	1"	1 1/2"	2"	2 1/2"	3"
<b>3/16"</b> 4.76 mm	<b>1/2</b> 12.7 mm	SOCKET ACCESSORY ASSEMBLY	18808	18809	18810	18811	18812	18813	18814
		SOCKET	18485	18486	18487	18488	18489	18490	18491
		JIFFY KEY STALL	18731	18732	18733	18734	18735	18736	18737
	<b>9/16</b> 14.29 mm	SOCKET ACCESSORY ASSEMBLY	18815	18816	18817	18818	18819	18820	18821
		SOCKET	18492	18493	18494	18495	18496	18497	18498
		JIFFY KEY STALL	18731	18732	18733	18734	18735	18736	18737
	<b>5/8</b> 15.87 mm	SOCKET ACCESSORY ASSEMBLY	18822	18823	18824	18825	18826	18827	18828
		SOCKET	18710	18711	18712	18713	18714	18715	18716
		JIFFY KEY STALL	18731	18732	18733	18734	18735	18736	18737
	<b>1 1/16</b> 17.46 mm	SOCKET ACCESSORY ASSEMBLY	18829	18830	18831	18832	18833	18834	18835
		SOCKET	18717	18718	18719	18720	18721	18722	18723
		JIFFY KEY STALL	18731	18732	18733	18734	18735	18736	18737
	<b>3/4</b> 19.05 mm	SOCKET ACCESSORY ASSEMBLY	18836	18837	18838	18839	18840	18841	18842
		SOCKET	18724	18725	18726	18727	18728	18729	18730
		JIFFY KEY STALL	18731	18732	18733	18734	18735	18736	18737